



Quick rope guide

Do your sheets or halyards need replacing? Not sure what the correct sizes are? Consult this quick reference guide to the key bits on your boat.

Name & Part No	Length (mm)	Diameter (mm)
Shroud DW330 (1)	5867 +/- 30	4.0 +/- 0.25
Forestay DW310 (1)	4357 +/- 20	3.0 +/- 0.25
Short Forestay DW320 (1)	775 +/- 10	4.0 +/- 0.25
Trapeze Wire DW280 (1)	5460 +/- 100	2.0 +/- 0.25
Bridle Wire DW300 (1)	1295 +/- 10	3.0 +/- 0.25
Mainsheet DS380	9000 +/- 1300	9.0 minimum
Jibsheet DS400	9000 +/- 1300	9.0 minimum
Traveller Line DS381	5000 +/- 2300	7.0 minimum
Spanner Line DM367 (1,3)	3470 +/- 50	5.0 minimum
Trapeze Shockcord DT202	2200 +/- 300	5.0 +/- 1.5
Reaching Line Shockcord DT204	1750 +/- 300	5.0 +/- 1.5
Main Halyard DM362	16300 +/- 500	5.5 minimum
Jib Halyard DM364 (2)	11900 +/- 500	3.5 minimum
Jibsheet Bridle DS401 (1)	1600 +/- 200	6.0 minimum
Reaching Line DS410	1300 +/- 150	4.5 +/- 1.0
Main Luff Downhaul DM360 (2)	850 +/- 400	4.8 minimum
Forestay Strop DW313 (2)	600 +/- 600	5.0 +/- 2.0
Jib Strop DS432 (2)	850 +/- 400	4.0 +/- 2.0
Trapeze Adjuster DW285 (2)	1500 +/- 200	5.0 minimum

(1) Length includes loop at both ends.

(2) Length includes a loop at one end.

(3) Measured under a tensile load of 4.5kg +/- 0.5kg

Please note If in doubt, please consult class drawings before replacement